OWNER'S MANUAL



www.geckomusicgroup.com



SAFETY INSTRUCTIONS & SYMBOLS GUIDE

For your own safety and to avoid invalidation of the warranty, all text marked with these symbols should be read carefully.

SYMBOLS:



NOTES Contain important information and useful tips on the operation of your equipment.



WARNING

The lightning flash with arrowhead symbol within an equilateral triangle, is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



CAUTIONS

The exclamation point within a equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance. Please read the manual carefully.



HEADPHONES SAFETY WARNING

Contain important information and useful tips (R) headphones outputs and monitoring levels.

SAFETY INSTRUCTIONS:

- To reduce the risk of electrical shock, do not remove covers. No user-serviceable parts inside. Please refer servicing to qualified personnel.
- To reduce the risk of electrical shock or fire, do not expose the equipment to rain or moisture.
- Do not impose unnecessary stress on your equipment (i.e. placing heavy objects on it, over screwing its mounting, etc).
- Read and keep the instruction manuals in a safe place for future references.
- Do not attempt to clean the equipment with chemical solvents as this may damage the finish. Clean only with a dry cloth.
- Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Do not defeat the purpose of the polarized or grounding-type plug. A polarized plug has two blades with
 one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide
 blade or the grounding prong is provided for your safety. If the provided plug does not fit into your outlet,
 consult an electrician for the replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Unplug the apparatus during lightning storms or when it is not in use for a long period of time.

- Use only attachments/accessories specified by the manufacturer.
- Always shut down power supply when not in use to save energy and for a prolonged lifespan.
- Exposure to extremely high noise levels may cause permanent hearing loss. Individuals vary considerably in susceptibility to noise-induced hearing loss, but nearly everyone will lose some hearing if exposed to sufficiently intense noise for a period of time. The U.S. Government's Occupational Safety and Health Administration (OSHA) and the Singapore Workplace Safety and Health Council (WSHC) has specified the permissible noise level exposures shown in the following chart. According to OSHA and WSHC, any exposure in excess of these permissible limits could result in some hearing loss. To ensure against potentially dangerous exposure to high sound pressure levels, it is recommended that all persons exposed to equipment capable of producing high sound pressure levels use hearing protectors while the equipment is in operation. Earplugs or protectors in the ear canals or over the ears must be worn when operating the equipment in order to prevent permanent hearing loss if exposure is in excess of the limits set forth here:

Duration/Day (Hours)	dB, Sound Pressure Level (SPL)	Descriptions
	Below 90dB	Safe zone
8.00	90	Hearing damage
6.00	92	
4.00	95	
3.00	97	
2.00	100	Serious hearing damage
1.50	102	
1.00	105	
0.50	110	
0.25 or less	115	Human pain threshold

FOREWORD

Dear Friends,

Thank you very much for purchasing quality products by **GECKO MUSIC GROUP**. I am very grateful that we have journeyed this far, since 2002! We have set new audio standards in the industry and we have touched and changed lives along the way! I believe our journey will not stop but continue to pursue more breakthrough findings and improvements that will change our lives for the better.

At **GECKO MUSIC GROUP** we focus on developing nothing but the best professional audio equipment and premium grade audiophile products you ever need! Our engineering team is constantly doing R&D to meet this goal. I thank God that by His grace, we have succeeded in developing the revolutionary C.R.I.S.T.A.L.® technology that has changed and is changing the way how audio is captured, encoded, reproduced and managed!

On behalf of **GECKO MUSIC GROUP**, I would like to pledge our continuing commitment to uphold our traditions in serving the music and audio communities around the world with more value-added premium quality GECKO® professional audio equipment and premium grade audiophile products!

Once again, thank you very much for your support. We trust you will love what you hear!

Yours truly,

Daniel Foo Founder/Director (R&D) **GECKO MUSIC GROUP**

TABLE OF CONTENTS

INTRODUCTION	1
SPEAKER ELEMENTS	2
MAKING CONNECTIONS	4
INSTALLATION CONSIDERATIONS	4
SPECIFICATION	5
WARRANTY	6



NOTES: This manual covers both the REVELATION SR 612RF 12" and the REVELATION SR 615RF 15" loudspeakers. As both loudspeakers are functionally identical, this manual will discuss the GECKO® REVELATION SR 615RF.

INTRODUCTION

The GECKO® REVELATION SR 612RF 12" and SR 615RF 15" 2-way audiophile-grade long-throw loudspeakers are designed to handle extremely demanding high Sound Pressure Levels (SPL) in live sound situations with ease. Both the SR 612RF and SR 615RF are designed to reproduce a remarkable audio precision with its GECKO® C.R.I.S.T.A.L.® technology.

The REVELATION SR 612RF and SR 615RF enclosures are also prepared with flexible installation features, making them the perfect choice for multi-style professional audio installations and applications such as frontof-house (FOH), side-fill, down-fill, rigged/suspended clusters/arrays, and as premium quality concert theater/studio reference monitors. The REVELATION SR 612RF and SR 615RF loudspeakers come equipped with C.R.I.S.T.A.L.® WaveGuide technology, where an equal-volume sound coverage is made possible!

The GECKO® REVELATION SR 612RF and SR 615RF include the following features and more:

- C.R.I.S.T.A.L.® WaveGuide optimizes widest coverage area for all applications
- Passive C.R.I.S.T.A.L.® audiophile crossover for natural, uncompressed, precise sound reproduction
- · Unique enclosure design provides multi-style mounting angles

SPEAKER ELEMENTS



1. GRILLE

Foam-backed, powder-coated perforated steel grille to protect the REVELATION SR 615RF's woofer and tweeter from possible damages contributed by external factors.

2. ENCLOSURE

All REVELATION series enclosures are made using Baltic birch plywood, oven-baked painted with textured wear-resistant black paint to ensure the best resonance and durability.

3. CARVED HANDLE

To ease the carrying of the REVELATION SR 615RF.

4. MOUNTING POINTS

These are 3/8" - 16 threaded mounting/rigging points. You can use these points to mount the REVELATION SR 615RF on a wall bracket, fly rigging system, rigged/suspended clusters/arrays system, and/or on any customized mounting/rigging system.

5. RECESSED PAN WITH STUD AND RING

You can use these to mount the REVELATION SR 615RF on a wall bracket, fly rigging system, rigged/suspended clusters/arrays system, and/or on any customized mounting/rigging system.

6. FLY TRACK WITH FLYING POINT

This is a 12-position fly track with a flying point. You can use this to mount the REVELATION SR 615RF on a wall bracket, fly rigging system, rigged/suspended clusters/arrays system, and/or on any customized mounting/rigging system.

7. POLE MOUNT CUP

Located at the bottom of the enclosure, the pole mount cup is commonly used to hold the REVELATION SR 615RF on a speaker stand.

8. CONNECTORS

These are 4-pole SPEAKON connectors. These connectors work both as INPUT as well as OUTPUT connectors.

MAKING CONNECTIONS

To connect the GECKO® REVELATION SR 615RF to your sound system, refer to the following steps:

- 1. Turn OFF all equipment before making any connections.
- 2. Mount the GECKO® REVELATION SR 615RF on a stand, wall bracket, fly rigging system, rigged/suspended clusters/arrays system, and/or on any customized mounting/rigging system according to the given setup/installation instructions and safety guidelines (optional accessories are sold separately).
- 3. For purest sound quality, make connections using only premium quality audio cables (i.e. GECKO® TRUTH T2, GECKO® TRUTH T3AL), connectors (i.e. GECKO® OLYMPIAN and GECKO® AUDIOPHILE connectors), amplifiers (i.e. GECKO® GENESIS ELEGANCE and DEFINITY AUDIO® amplifiers), and mixing consoles (i.e. GECKO® EXODUS series mixing consoles) according to your requirements.
- 4. Turn ON all equipment after making connections. Alternatively, you could set up the power-up and down sequence of your system using the GECKO® GALILEE CLASSIC PSC 8330 power sequencer for optimum protection.


INSTALLATION CONSIDERATIONS

HOOKUPS AND CABLING

The GECKO® REVELATION SR 615RF is designed with 8Ω impedance. The two 4-pole SPEAKON connectors at the back are wired in parallel and function as both OUTPUT and INPUT connectors. Either one of these connectors can be used to hookup to another GECKO® REVELATION SR 615RF in parallel when necessary. It is recommended that you do not hookup (in parallel) more than two units of GECKO® REVELATION SR 615RF per amplifier channel.

INPUT AND OUTPUT CABLE CONFIGURATIONS

The following diagram illustrates the polarities and connections of the GECKO® REVELATION SR 615RF.



SPECIFICATION

Speaker:

GECKO® REVELATION SR 612RF: 12" Woofer with Diecast Aluminium Frame GECKO® REVELATION SR 615RF: 15" Woofer with Diecast Aluminium Frame

Tweeter:

40mmø C.R.I.S.T.A.L.® Driver

Max RMS: GECKO® REVELATION SR 612RF: 500W GECKO® REVELATION SR 615RF: 700W

Impedance: 8Ω

Frequency Response: 45Hz ~ 20kHz (C.R.I.S.T.A.L.® Audiophile Linear Response)

Nominal Coverage: C.R.I.S.T.A.L.® WaveGuide 90° (H) x 60° (V) Coverage

Sensitivity:

110dB/W/m

Physical Properties: GECKO® REVELATION SR 612RF:

Enclosure: 18mm Baltic Birch Plywood Finish: Wear Resistant Textured Black Paint Hardware: 6 x 3/8" - 16 Threaded Mounting/Rigging Points, 5-Position Fly Track with Flying Point (Top), 2 x Recessed Pan with Stud and Ring (Rear), 1 x Pole Mount Cup (Bottom) Grille: Powder Coated Perforated Steel, Foam-Backed (Black) Connectors: 4-Pole SPEAKON (2) Net Weight: 22.5kg Dimension: (H) 640mm x (W) 390mm x (D) 427mm **GECKO® REVELATION SR 615RF:** Enclosure: 18mm Baltic Birch Plywood Finish: Wear Resistant Textured Black Paint Hardware: 6 x 3/8" - 16 Threaded Mounting/Rigging Points, 12-Position Fly Track with Flying Point (Top), 2 x Recessed Pan with Stud and Ring (Rear), 1 x Pole Mount Cup (Bottom) Grille: Powder Coated Perforated Steel, Foam-Backed (Black) Connectors: 4-Pole SPEAKON (2) Net Weight: 26.1kg Dimension: (H) 660mm x (W) 463mm x (D) 483mm

Specifications subject to change without prior notice. Manufactured under ISO9000 certified management system.

WARRANTY

GECKO MUSIC GROUP warrants its GECKO® products for a period of one (1) year from the original date of purchase, in accordance to the warranty regulations described below.

What is Covered:

During the applicable warranty period, GECKO MUSIC GROUP warrants the product against defects in materials and workmanship and against malfunctions. GECKO MUSIC GROUP will remedy all such defects and malfunctions without charge for parts or labour if the warranty applies. In the case that other parts are used which constitutes an improvement, GECKO MUSIC GROUP may, at its discretion, charge the customer for the additional cost of these parts. Final determination of warranty coverage lies solely with GECKO MUSIC GROUP.

What is Not Covered:

- 1. If the product needs to be modified or adapted in order to comply with applicable technical or safety standards on a national or local level, in any country which is not the country where the product was originally developed and manufactured, this modification/adaptation shall not be considered a defect in material or workmanship;
- 2. Normal wear and tear, in particular, of faders, crossfaders, potentiometers, keys/buttons, valves, guitar/bass strings, machine heads, pick-up covers, PVC/PU/leather covers, illuminants, and similar parts are not covered by this warranty;
- 3. Improper handling, neglect or failure to operate the unit in compliance with the instructions given in the user or service manuals;
- 4. Connection or operation of the unit in any way that does not comply with the technical or safety regulations applicable in the country where the product is used;
- 5. Damages/defects caused by force of nature or any other condition that is beyond the control of GECKO MUSIC GROUP;
- 6. Any repair or opening of the unit carried out by unauthorized personnel (user included) will void the warranty;
- 7. Modification or removal of serial numbers.

Obtaining Warranty Service:

To return a GECKO® product for warranty service, first fill out the <u>Online Technical Report</u> on this website and submit for an authorization/service number. Write the authorization/service number so that it is prominently displayed on the outside of the shipping carton. Any products received without an authorization/service number that is clearly visible upon arrival at the factory will be refused. Enclose proof of the original delivery date or a copy of the original sales receipt/invoice. Enclose a description of the suspected defect or malfunction and the condition, if any, which caused the problem. Return the product to either GECKO MUSIC GROUP or the GECKO® Store where the purchase was made. Note: Before sending back to GECKO MUSIC GROUP, you can first check with your local GECKO® Store or authorized reseller where you buy from for support.

Warranty Shipping:

You are responsible for prepaying shipping costs F.O.B. GECKO MUSIC GROUP, Singapore. Shipped product(s) must be properly packaged. Use original shipping cartons and packing materials where possible. GECKO MUSIC GROUP is not responsible for damages resulting from inadequate and or improper packing.

Products received with damages due to improper packaging will be deemed out of warranty.

Products which do not meet the terms of this warranty will be repaired exclusively at the buyer's expense. GECKO MUSIC GROUP will inform the buyer of such circumstance. If the buyer fails to submit a written repair order within six (6) weeks after notification, GECKO MUSIC GROUP will return the unit C.O.D. with a separate invoice for freight and packing. Such costs will also be invoiced separately when the buyer has sent in a written repair order.

Warranty Rights:

This warranty is exclusive and extended to the original buyer and is not transferable to anyone who may subsequently purchase this product. No other person (apart from authorized GECKO® Stores) shall be entitled to give any warranty promise on behalf of GECKO MUSIC GROUP.